



### Bag contents:

- 5 - 2" flat-head screws (A)
- 5 - plastic barrel nuts (A)
- 6 - 1 1/4" flat-head screws (1A,D & 2B,C)
- 5 - 5/8" tapered screws (4A & 1C)
- 2 - 3" bolts w/wing nut & washer (B)
- 4 - 1/2" flat-head screws (C)
- 4 - 1/2" tapered screws (C)
- 1 - ratchet locking device (C)
- 1 - small block of wood (C)

1. Attach the 2 side legs (#1 & 2) to the crossbars (#3 & 4) using the 2" screws & the barrel nuts. The shorter crossbar (#3) goes towards the top with the larger holes facing the back. Place one nut, with the groove facing outward, in a larger hole. The groove should be aligned to match the angle of the screw when it is inserted in the hole. Insert a 2" screw from the outside of #1, through #3, the nut, then tighten. The nut enables the screw to remain tightened. The legs have the angled end towards the floor & pointed end forward. Repeat for the other side using #2. (**See Illustration 1**)
2. Place #4 near the bottom and attach it to #s 1 & 2. Use two more 2" screws and nuts repeating step 1. Using the four 1/2" tapered screws attach the hinged piece (#5) to the back of the top crossbar (#3). Place the oval hole towards the bottom.
3. Use a 1 1/4" screw to attach #3 to the wood piece with metal steps (#6). Place the end of #6 with more holes towards the top. Do not attach the bottom of #6 to the bottom crossbar (#4) yet as you will be sliding the canvas tray up through #6 later.
4. Attach the two 7 5/8" x 3/4" wood pieces to #6 and back leg #7 using the two 3" screws with wing nuts and washers. Put the screw through the wood piece, the slit in the back leg, the other wood piece, the washer & tighten with wing nut (**See Illust. 2**).
5. Put the last barrel nut in the hole near the top of the back leg and the 2" screw through #5 on the top of the crossbar and tighten.
6. Use two 1 1/4" screws to attach the top mast holder (#8) to the top crossbar (#3).
7. Screw the other hinged piece #9 to the small block of wood that came in a plastic bag using two 1 1/4" screws. (**See Illust. 3**)
8. Turn the canvas tray (#10) upside down and screw the hinges on #9 to #10 using the four 1/2" tapered screws. Have the piece face outward of the tray. Screw the locking device also to the canvas tray (#10) using four 1/2" flat-head screws.
9. Place the oval wedged bottom of the mast (#11) into the canvas tray (#10). Use a 1 1/4" screw to secure #11 to #10.
10. Slide the canvas tray (#10) up through the bottom of #6 (**See Illust. 4**). Pull back the gold lever while sliding #6 through #10, then release it once it is through. At the same time, slide the mast through #8 to hold top into place (**See Illust. 4**). Screw the bottom of #6 to #4 using 1 1/4" screw. Slide the top canvas holder (#12) onto the top of the mast (#10) and tighten.