



Shelf Help Parts:

- A.) Back piece of Shelf Help with 2 elastic straps
- B.) Short bottom brace
- C.) Long bottom brace
- D.) Shelf Help tray
- E.) Plastic brush holder

Shelf Help Assembly:

Lay out the Shelf Help parts as shown in the above illustration. Assemble the Shelf Help tray by inserting the long and short bottom braces into the notches on the Shelf Help tray. Next, slide the back piece down over the lip of the back of the Shelf Help tray. Finally, secure the Shelf Help on to the side of your French easel. Remember to put the left hand shelf (696306) on the left side of the easel and the right hand shelf (696305) on the right side of the easel. The brush holder can be secured into the small velcro strap for easy accessibility.

Please note: Depending on your own French Easel, you may need to pull the drawer farther out to accommodate the Shelf Help. The back bottom brace should attach to the easel box *behind* the drawer, while the front bottom brace gets attached to the drawer itself.

