




Jack Richeson
& Co., Inc.


HOW TO ASSEMBLE THE Giant Dulce Easel

#840201 Made from Lyptus® Wood

Imported Easels by Jack Richeson & Co., Inc. - Kimberly, WI - Phone: 1-800-233-2404 - www.richesonart.com 8/09



Please open box, take out all pieces and check for damage before beginning assembly.



1. 4 - Adjustable Feet
2. 2 - Slide Guides
3. 2 - 1³/₈" Plastic Washers
4. 2 - 2¹/₂" Bolts
5. 2 - Black Knobs
6. 7 - 1³/₈" Wood Screws


Step One:

Assemble Bottom Canvas Holder. Secure Part #1 (E) to Part #2 (F) using 4 wood screws.



Step Two:

Assemble Easel Frame Assembly (D) by using 2 Bolts, 2 Slide Guides, 2 Plastic Washers and 2 Black Knobs.



Easel Dimensions:

- Maximum canvas height: 87"
- Base width/depth: 22¹/₂" x 30"
- Extended easel height: 112¹/₂"
- Compact easel height: 62"
- Bottom painting tray width: 30"
- Box dimensions: 23¹/₂" x 69¹/₂" x 4"
- Shipping weight: 38lbs.



Jack Richeson
& Co., Inc.

HOW TO ASSEMBLE THE Giant Dulce Easel

#840201 Made from Lyptus[®] Wood

Imported Easels by Jack Richeson & Co., Inc. - Kimberly, WI - Phone: 1-800-233-2404 - www.richesonart.com 8/09


Step Three:

Insert Leveling Feet. (H) You can now stand the easel up for the remainder of the assembly.




Step Four:

Secure Bottom Mast Stop (G) with 3 screws. Insert Mast (B) from top.



Step 5



Step Five:

Slide on Top Canvas Holder (A) and the assembled Bottom Canvas Holder (E & F).

Note: you may need to loosen the black knobs on both pieces before sliding onto the mast.

