




BEST
Easels by Richeson

HOW TO ASSEMBLE THE Halley Easel #880600

BEST Artist's Materials - A Richeson Co. - Kimberly, WI - Phone: 1-800-233-2404 - www.richesonart.com 3/16




The Elevator Bolt Locking System is used on top trays on Best easels. The 2 metal plates and round plastic guide keep the parts parallel which

allows for smoothness and ease when the tray is moved into position. By tightening the knob, the circular plate will seal itself against the mast. This means ultimate stability for the canvas.


Box should contain:

- 6 - 2 1/4" carriage bolts with knobs
- 4 - 1 1/2" carriage bolts
- 2 black plastic slide guides
- 1 painting tray with pre-assembled wedge-lok system
- 5 easel parts
- 1 stainless steel cup
- 1 melamine painting tray





Height & tray adjustments unlock easily, yet lock into place & stay locked because of the Wedge-lok System. The metal plate features wedge-cut edges that conform

to the wedge-cut sections of the hardwood. When the knob is tightened, the inward tension pulls the metal plate snugly against the wood for a solid lock.




Slide Guides make angle and height adjustments on Best easels smooth. These circular graphite impregnated plastic inserts are used


wherever there is a slot in the wood of the easel. This part allows for smooth movement and protects the hardwood from the metal bolt.




Base




Back Brace



Center Mast



Frame



Bottom Canvas Tray