



# HOW TO ASSEMBLE THE Terrero Taboret #886003 Deluxe Table Top Easel #884200 Sold Separately

BEST Artist's Materials - A Richeson Co. - Kimberly, WI - Phone: 1-800-233-2404 - www.richesonart.com 3/16




Height & tray adjustments unlock easily, yet lock into place & stay locked because of the Wedge-lok System. The metal plate features wedge-cut edges that conform

to the wedge-cut sections of the hardwood. When the knob is tightened, the inward tension pulls the metal plate snugly against the wood for a solid lock.



Slide Guides make angle and height adjustments on Best easels smooth. These circular graphite impregnated plastic inserts are used

wherever there is a slot in the wood of the easel. This part allows for smooth movement and protects the hardwood from the metal bolt.



## TERRERO (Taboret) #886003

- Height: 32-1/4", Width: 22-1/4", Depth: 22"
- Offers a 4" high outer supply drawer, a 3 1/2" inner drawer, a slide out utility shelf & storage space.
- 1 1/8" slots for secure mounting of optional table easel.
- When the Deluxe Table Top Easel is mounted on the Terrero and folded flat, it may be used for varnishing, gessoing or watercolor work.
- Mounted on front locking rubber casters for mobility.
- Packaged in heavy-duty carton for protection.
- Shipping Weight: 78 lbs.
- Ships UPS, some assembly required.

## DELUXE TABLE TOP #884200 SOLD SEPARATELY

- Holds canvases up to 36".
- Extended height: 47"
- Base width/depth: 18" x 18"
- Expandable mast with movable canvas holders.
- Patented Slide Guides.
- Ships fully assembled weighing 14 lbs.

*Is it a storage taboret or a counter to mount your table top easel? It's both! Strength and durability are just two of the qualities of this beautiful, solid oak taboret. It is finished on all four sides so that it can be used either in the center of the room or against a wall. The center top section is designed to securely hold the BEST Deluxe Table Top Easel which can be purchased separately.*

## Taboret Assembly - Terrero

- 1.) Take the Terrero unit out of the box (We would recommend assistance if possible). **Do not open the top shelves until folding wing supports are attached!** The hinged shelves will break off if support wings are not attached first.
- 2.) Locate hardware and folding wing supports (triangular shaped pieces of wood). The wing supports and the side of the Terrero have already been predrilled and fitted for three screws, so all you need is a Phillips screwdriver to mount the supports. If predrilled holes don't match up at first, switch sides.
- 3.) The bottom of the Terrero has predrilled holes for the four casters. Mount these and you will be all set.
- 4.) If you purchased a Deluxe Table Top Easel, all that is necessary for use is setting the easel into the slots on the top of the Terrero and adjusting the easel to the desired position.