


# PASTEL BOX INSTRUCTIONS

## remove quick release plate from tripod



Remove quick release from Sienna tripod (sold separately).

- Squeeze levers together and rotate backward.
- Plate will release from the ballhead.

## 1 attach tripod quick release to pochade box and to ballhead




- Turn pochade box upside down.
- Thread quick release plate into mounting bracket.
- Tighten plate screw with screwdriver to ensure a strong fit.



- Place plate into open ballhead.
- Press down firmly until ballhead handles snap closed. Firmly press handles to seat quick release plate.
- Loosen ballhead adjustment and move pochade to desired angle, re-tighten.

## 1 opening the pastel box



- Unlock latch on front of pochade box.
- Loosen the 3 knobs on left side of box.
- NOTE: To open lid completely flat for watercolor leave support arm in closed position and follow steps 2 and 3.

## 2 IMPORTANT: slide support arm all the way to rear position



- Slide support arm toward rear of box until it stops. This provides all the support for the lid and is a **VERY IMPORTANT** step!
- Tighten front knob of support arm to lock support arm in place.

## 3



- Lift lid to desired working angle and tighten lid support knob.
- Tighten lid stabilizing knob.

## 4 remove pastel cover



- Remove the protective foam cover to access pastel compartment.
- NOTE: Always put foam cover in place before closing pastel box.

## 5 removable dividers



- The pastel box features four pastel compartments.
- The compartment dividers can be removed to clean the pastel box and the protective foam sheet.


## accessory tray/brush holder



The accessory tray can hold pastels and other tools and small accessories. It is held on the rear of the lid with two magnets.

- Grip accessory tray brackets and pull away from the lid.
- Attach accessory tray to the right side of the box.

## adjusting the panel holders



The pastel box can hold panels, pastel board and mounted pastel paper.

- Loosen 2 knobs on rear of lid.
- Raise or lower to desired position. Re-tighten knobs.