


POCHADE BOX INSTRUCTIONS

remove quick release plate from tripod



Remove quick release from Sienna tripod (sold separately).


- Squeeze levers together and rotate backward.
- Plate will release from the ballhead.

1 attach tripod quick release




- Turn pochade box upside down.
- Thread quick release plate into mounting bracket.
- Tighten plate screw with screwdriver to ensure a strong fit.

2 attach quick release to ballhead




- Place plate into open ballhead.
- Press down firmly until ballhead handles snap closed. Firmly press handles to seat quick release plate.
- Loosen ballhead adjustment and move pochade to desired angle, re-tighten.

1 opening the pochade box



- Unlock latch on front of pochade box.
- Loosen the 3 knobs on left side of box.
- NOTE: To open lid completely flat for watercolor, leave support arm in closed position and follow steps 2 and 3.

2 IMPORTANT: slide support arm all the way to rear position



- Slide support arm toward rear of box until it stops. This provides all the support for the lid and is a **VERY IMPORTANT** step!
- Tighten front knob of support arm to lock support arm in place.

3



- Lift lid to desired working angle and tighten lid support knob.
- Tighten lid stabilizing knob.


accessory tray/brush holder



The accessory tray can hold pastels and other tools and small accessories. It is held on the rear of the lid with two magnets.

- Grip accessory tray brackets and pull away from the lid.
- Attach accessory tray to the right side of the box.

adjusting the panel holders



The pastel box can hold panels, pastel board and mounted pastel paper.

- Loosen 2 knobs on rear of lid.
- Raise or lower to desired position. Re-tighten knobs.

using the palette blocks (holds the glass palette in place)



- Two small magnetic block hold the tempered glass palette in place when the palette box is closed.
- Remove the magnetic blocks and use the hole in the bottom to push up the edge of the glass palette.



Supply Box (sold separately)

The Supply Box is the perfect accessory for easy access to paints and brushes. It fits on the front two legs of the Sienna Tripod.

Adjust height of supply box on tripod with the 2 adjustable leg blocks. Set the supply box on the open Sienna Tripod. Open lid and use as a work surface.

Paper towel holder is included with supply box. It attaches on the front or sides of box.